

© Copyright reserved. This drawing may not be reproduced or amended without prior written permission.

> Detail issued for Guidance Only. Designer's Approval Required.

Site construction sequencing should be assessed before the appropriate Visqueen Standard Detail is selected & approved by the Designer.

In order to develop a robust design for protecting a structure against groundwater, a Risk Assessment must be carried out in line with the guidance given in BS8102:2009.

The Designer may need to specify one or a combination of waterproofing

All Visqueen materials must be installed in strict accordance with the manufacturer's instructions. Refer to the current Visqueen datasheets.

Do Not Scale - Use Figured Dimensions

Standard Detail



www.visqueen.com

Scale: NTS

Date : Dec.2018

Drawing No : GB-21

VISQUEEN 0333 202 6800

www.visqueen.com enquiries@visqueen.com



Typical Edge Detail - Ground Bearing Slab.