



Step 1

Fully bond a strip of Visqueen 100mm Double Sided Tape onto the cavity tray

Step 2

Fully bond the bespoke Visqueen Preformed Jamb Cloak onto the Visqueen Double Sided Tape

See Visqueen Standard Detail PFU-131 for bespoke Jamb Cloak

Door threshold DPC

Typical Jamb Cloak BUILD SEQUENCE DRAWING

NB; DO NOT SCALE - USE FIGURED DIMENSIONS ONLY.



Visqueen
 Contact Technical Support :
 t : 0333 202 6800
 f : 0333 202 6886
 e : enquiries@visqueen.com
 www.visqueen.com

Project : Typical Jamb Cloak Build Sequence Drawing (Blockwork Closer Condition).

Drawing No.- PFU-208.

Date.- 12/18.

Scale.- NTS.

© COPYRIGHT RESERVED.