


KEY TO MATERIALS :-	
1	Visqueen High Performance DPM on smooth well compacted blinding layer.
2	Visqueen Axiom Guard (2 coats) on Axiom Guard Primer.
2a	Visqueen Axiom Guard (1 coat) on Axiom Guard Primer.
3	Visqueen Double Sided Jointing Tape.
4	Visqueen Pro 300mm Detailing Strip.
5	Visqueen TreadGUARD 300 or 1500.
6	Visqueen Protect&Drain.
7	Visqueen Vapour Barrier.
8	Visqueen Axiom CreteSeal.



© Copyright reserved. This drawing may not be reproduced or amended without prior written permission.

Detail issued for Guidance Only. Designer's Approval Required.

Site construction sequencing should be assessed before the appropriate Visqueen Standard Detail is selected & approved by the Designer.

In order to develop a robust design for protecting a structure against groundwater, a Risk Assessment must be carried out in line with the guidance given in BS8102:2009.

The Designer may need to specify one or a combination of waterproofing measures.

All Visqueen materials must be installed in strict accordance with the manufacturer's instructions. Refer to the current Visqueen datasheets.

Do Not Scale - Use Figured Dimensions Only.

Detail is subject to SE approval.

Standard Detail



www.visqueen.com

Scale : NTS

Date : April.2020

Drawing No : AX-18



Typical Perimeter Concrete Upstand Detail 1.

VISQUEEN
0333 202 6800
www.visqueen.com
enquiries@visqueen.com