


**KEY TO MATERIALS :-**

|   |   |
|---|---|
| 1 | Visqueen Ultimate RadonBlok 600.                |
| 2 | Visqueen Zedex CPT DPC.                         |
| 3 | Visqueen GR SAM on Visqueen HP Tanking Primer.  |
| 4 | Visqueen RadonBlok Double Sided Tape.           |
| 5 | Visqueen Pro Single Sided Tape.                 |
| 6 | Visqueen Vapour Barrier.                        |
| 7 | Visqueen Pro Vapour Edge Tape.                  |
| 8 | Visqueen Zedex CPT DPC Preformed Top Hat Cloak. |
| 9 | Jubilee clip.                                   |



© Copyright reserved. This drawing may not be reproduced or amended without prior written permission.

Detail issued for Guidance Only. Designer's Approval Required.

Site construction sequencing should be assessed before the appropriate Visqueen Standard Detail is selected & approved by the Designer.

In order to develop a robust design for protecting a structure against groundwater, a Risk Assessment must be carried out in line with the guidance given in BS8102:2009.

The Designer may need to specify one or a combination of waterproofing measures.

All Visqueen materials must be installed in strict accordance with the manufacturer's instructions. Refer to the current Visqueen datasheets.

Do Not Scale - Use Figured Dimensions Only.

**Standard Detail**



[www.visqueen.com](http://www.visqueen.com)

Scale : NTS

Date : Dec.2018

Drawing No : RADBLOK-15



**Typical Edge Detail 1 - Ground Bearing Slab.**

**VISQUEEN**  
0333 202 6800  
[www.visqueen.com](http://www.visqueen.com)  
[enquiries@visqueen.com](mailto:enquiries@visqueen.com)