

**KEY TO MATERIALS :-**

© Copyright reserved. This drawing may not be reproduced or amended without prior written permission.

Detail issued for Guidance Only. Designer's Approval Required.

Site construction sequencing should be assessed before the appropriate Visqueen Standard Detail is selected & approved by the Designer.

In order to develop a robust design for protecting a structure against groundwater, a Risk Assessment must be carried out in line with the guidance given in BS8102:2009.

The Designer may need to specify one or a combination of waterproofing measures.

All Visqueen materials must be installed in strict accordance with the manufacturer's instructions. Refer to the current Visqueen datasheets.

Do Not Scale - Use Figured Dimensions Only.

**Standard Detail**



[www.visqueen.com](http://www.visqueen.com)


Scale : NTS

Date : Dec.2018

Drawing No : RADBLOK-19

**VISQUEEN**  
0333 202 6800  
[www.visqueen.com](http://www.visqueen.com)  
[enquiries@visqueen.com](mailto:enquiries@visqueen.com)

1	Visqueen Ultimate RadonBlok 600.	6	Visqueen VX25 Waterstop.
2	Visqueen Ultimate RadonBlok 600.	7	Visqueen Waterstop Mastic.
3	Visqueen Pile Cap Sealer.	8	Visqueen VX90 Waterstop.
4	Visqueen RadonBlok Double Sided Tape.	9	Visqueen TreadGUARD 1500.
5	Visqueen Pro Single Sided Tape.		



**LOW RISK DETAIL**



**Typical Pile Detail - Ground Level  
DPM - Low Risk.**